

^{*}It is possible to isolate the Stock Fuel Filter in some circumstances. to allow for a faster purge cycle. This also eliminates the second layer of defense and protection that the stock fuel filter offered. Please be aware of this. The stock fuel pump must be plumbed so that both fuels route through it.