


## Relay Arrangements on the Relay Panel

- 1** Dual Horn Relay (53)
- 2** Load Reduction Relay (18/100)
- 3** Open
- 4** Fuel Pump (FP) Relay (409)
- V** Wiper/Washer Intermittent Relay
- VI** Vehicles without headlight washer system (377)  
Vehicles with headlight washer system (389)  
Vehicles with Rain Sensor (192)



## Fuse Placements on the Relay Panel

- A** Power (memory) Seat Circuit Breaker (30 Amp)
- B** S283 Brake Vacuum Pump Fuse for V192 - Brake System Vacuum Pump (15 Amp)  
(beginning May 2002), S51 Fuse for Telematic (20 Amp)
- C** Fuse or Power Windows (circuit breaker) (30 Amp) central Locking system, heated power Mirrors,  
(vehicles with Comfort System and Power Windows only)